



**ULTRATECH**  
INTERNATIONAL, INC

## Ultra-Parking Stop Protector®

### Installation Instructions

PLEASE READ THROUGH ALL INSTRUCTIONS PRIOR TO INSTALLATION

1. Test fit to ensure the Ultra-Parking Stop Protector fits all stops on site.

NOTE: Use a heavy-duty construction adhesive such as LOCTITE UR 3370 WH (Part# 1535077) or TEROSON MS 5555NA WH (Part# 2337866)

NOTE: If another brand is used, be sure the adhesive used is compatible with plastics. A caulking gun is required for the next step. These items are not included and should be purchased prior to installation.

2. Apply adhesive to the top and front impact area of the concrete parking stop. Use a generous bead. (One 10 oz. tube of adhesive should provide enough coverage for 3 - 4 Parking Stops).
3. Place one corner of the Protector on one end of the parking stop and slowly lower it down to completely cover the stop.
4. Press the front of the Protector onto the parking stop to ensure a good fit.
5. Follow adhesive instructions for cure time before use.

