



Ultra-Containment Berm® Foam Wall Plus Models Setup Instructions

POSITIONING & PREPARATION

1. Bring palletized Berm to site where it will be deployed.
2. Check area for any debris (rocks, sticks, holes) that may damage the Berm when weight from vehicles, drums, equipment is added.
3. If possible/practical sweep area before deploying the Berm.



INSPECTION

1. Unroll Berm and inspect liner and Foam Supports for any damage that may have been caused during shipping. Please contact UltraTech immediately so that a claim can be filed with the freight company.



DEPLOYMENT

1. If no damage is found, complete unrolling Berm (if necessary) and position it as needed.
2. Depending on the size, the Ultra-Foam Wall Plus Berm may be shipped with some of the Foam Wall Supports pre-installed and others separate. If needed, install remaining Foam Wall Supports. HINT: String or rope (not included) can be tied to grommets if pulling the Supports is preferred.
3. The Ultra-Foam Wall Plus Berm is now ready to be used.

