



ULTRATECH
INTERNATIONAL, INC

Ultra-Filter Pad®

Installation and Maintenance Instructions

Part# 6540 - Small Filter Pad
Part# 6541 - Medium Filter Pad
Part# 6542 - Large Filter Pad

Part# 6550 - Replacement Liners (4-pk), Small
Part# 6551 - Replacement Liners (4-pk), Medium
Part# 6552 - Replacement Liners (4-pk), Large

INSTALLATION:

1. Remove the Ultra-Filter Pad from the box and place in the area where it is to be used.
2. Insert one Ultra-Filter Pad Liner into the Ultra-Filter Pad. Be sure to tuck the edges of the liner under the foam walls of the Ultra-Filter Pad. The liner should be tucked completely into each of the corners. There are four strips of “hook” (one located on each sidewall of the Ultra-Filter Pad), which hold the liner to the pad.
3. During use, the Ultra-Filter Pad Liner will absorb hydrocarbons while allowing water to pass through the unit.

Maintenance and disposal:

When the Ultra-Filter Pad Liner is saturated with oil, simply dispose of it per local, state and federal regulations and replace it with a new Ultra-Filter Pad Replacement Liner (Part #6550, Part #6551, and Part #6552).

